

## **Extractor How To**

#### **Before Each Use**





- Check electrical cords for any breaks or tears
- Fill clean water solution tank 3 inches below the top lip
- Check all hose connections



- Plug extractor into wall
- Adjust handle before using





• Vacuum area to be cleaned and remove any large debris

### **During Use Operating**





- Adjust floor brush so that machine moves gently with little resistance. (This will be tested by turning the brush on)
- When brush adjustment is made, turn on vacuum.



- Move at a comfortable, but productive pace
- Be sure to overlap your cleaning edges by 2-6 inches





- vacuum to pick up residual moisture 3 feet after solution has stopped being used
- Unplug electrical cords and wrap appropriately



# **Extractor How To**

#### At the End of Each Use of Your Advance Extractor






- Drain and thoroughly rinse the dirty water recovery tank
- Drain and rinse cleanwater tank





- Remove brush, rinse and remove all fibers wrapped around brush – use razor or knife if necessary
- Remove and rinse tank filters
- Remove and thoroughly rinse and wipe off vacuum shoe





 Check spray nozzles and wipe off with clean towel





• Store machine with brush in "up" position